



General purpose cleaner for stone/linoleum/PVC

The Kärcher general cleaning agent for stone, linoleum and PVC allows you to thoroughly remove old protective layers and stubborn dirt from stone, linoleum and PVC. For the best results when using this general purpose cleaner, use together with Kärcher care products. This product can also be used for normal cleaning of sealed parquet and cork, however, it is not suitable for unsealed wooden surface



Properties

- Thorough cleaning
- Removes old coatings
- Removes stubborn dirt
- Base for new coating
- The body of the bottle is made from 100% recycled plastic.
- Made in Germany

Application areas

Stone floors
Linoleum floors
PVC floors

Usage options

- Manual

Technical data

Container sizes	Packaging unit	Part number
1 l	6 Piece(s)	6.295-775.0

Application

For thorough removal of old layers and stubborn dirt

- Vacuum the floor.
- Add 100 ml / L of basic cleaning agent to the water and spread evenly using a mop.
- Let it take effect but do not let it dry out. Mop again once or twice with clean water.

For normal stains

- Vacuum the floor.
- Add 100 ml of the basic cleaning agent to 5 L of water and wipe the floor with a damp mop.

Instructions for use

- Not suitable for unsealed wooden surfaces.

Warnings and safety recommendations according to EC Directives

- H290 May be corrosive to metals
- H319 Causes serious eye irritation
- P101 If medical advice is needed, have product container or label at hand.
- P102 Keep out of reach of children.
- P234 Keep only in original packaging.
- P264 Wash thoroughly after handling.
- P280i Wear eye/face protection.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P337 + P313 If eye irritation persists: Get medical advice/attention.
- P406 Store in a corrosion resistant container / container with a resistant inner liner.