

Plastic cleaner RM 625

For the thorough cleaning of garden furniture, PVC window frames, children's slides and other plastic surfaces. Very gentle on materials.



Properties

- Powerful, intensive and gentle
- Cleans, protects and maintains garden furniture, garden tools, plastic window frames and other plastic surfaces
- For cleaning all sensitive plastic surfaces, can be used universally
- Effectively dissolves oil, grease and mineral stains
- Can be used manually
- Ready-to-use detergent (RTU)
- Quick and efficient cleaning in combination with a Kärcher high-pressure cleaner
- Tailored to Kärcher devices with guaranteed material compatibility
- Made in Germany

Application areas

Garden tools and equipment
Garden/terrace/balcony furniture
Plastic

Usage options

- High-pressure cleaners
- Manual

Technical data

Container sizes	Packaging unit	Part number
5 l	1 Piece(s)	6.295-358.0

Application

With pressure washer or manually

- Dispense using the pressure washer or mix (1:10) in a bucket and apply using a sponge. Let it work in for a short while, then rinse well.

