

Assembly instruction nappy wallchanger

Parts delivered:

- 1x nappy wallchanger
- 1x wall hanging plate -
- 1x changing mat
- 4x security screws (2 pcs. M8x16, 2 pcs. M6x25)
- 2x allen keys

Carrying out the assembly:

- Drill the holes for attaching the wall plate. As there are many different walls (timber, concrete, clay etc.) it is important that you use the correct dowel for your wall. Kindly ask a skilled worker or a DIY Market about the correct fitting material.
- We recommend a working height of 95 cm (floor/open changing flap) see also: www.timkid.com/service
- Hang the wallchanger onto the wall hanging plate and fix it with the four security screws.

Please note!

- **Your child may never be allowed to lie on the changing table unobserved!**
- Please check the tightness of all assembled parts regularly.
- Please avoid direct heat near the changing table (as electric heaters or gas-fired ovens).
- Recommended for children up to 15 Kg (maximum weight 50 Kg).
- Additional parts or replacement parts are only available through timkid company.
- Please do not use the wallchanger if any part is broken or missing.
- Cleaning instructions for wood and laminate surfaces and the changing mat: wipe damp, possibly using standard disinfectant.
- **Note!** Used in a public area a [daily check](#) is recommended.